

Air Sampling Techniques 1

Diffusive (passive) Sampling

Tenax TA

Suitable for VOC (Volatile Organic Compounds) with the boiling point range +60° C to +250° C

Formaldehyde Dosimeter Badge

For formaldehyde in air

Pumped Sampling

A variety of different adsorbents and absorption solutions is available.

Air sampling Techniques 2

**Pumped
Sampling**

**Battery powered pumps
AC operated pumps**

Charcoal tubes

For workplace and indoor samples

Charcoal tubes according to K. Grob

For outdoor and indoor samples

Tenax TA and other porous polymers

For outdoor, indoor and workplace samples

DNF filters (dinitro phenyl hydazine)

For formaldehyde in air

And many other adsorbents